

Воздуходувки для спа-бассейнов серии APR V2/Z

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: axh@nt-rt.ru || сайт: <https://lx.nt-rt.ru>



LX Air blower (APR800V2/APR900V2/APR900-Z), LX Hot Tub SPA Air Blowers:

LX Air blower (APR800V2/APR900V2/APR900-Z)

I. Feature:

LX Air Blower:APR series hot tub spa air blowers has many configurations, filter is an option. It has the function to reduce the high-frequency interference from electric network, quick-dry heater is available; ozone generator and speed-adjustable PCB are available, with the characteristics of large air flow, large air pressure, low noise, easy installation, long life. They are double impeller air blowers. The casing is high reinforce and high temperature resistant engineering plastic. They are the best choice products for small hydromassage bathtub and SPA large pool making bubble.

Motor: low-noise air blowers' dedicated excitation motor which with dedicated thermal protection (VDE or UL approval) that can protect the motor. Insulation class F and with thermal protection from T.I. The carbon brush of the motor is import material. The life is greater than or equal to 1000 hours (continuous duty).There is fuse inside the motor, pneumatic switch control for easy operation.

Certification: 1. 3C China mandatory safety certification
2. CE European Union mandatory safety certification
3. TUV German safety certification.

Installation type:

1. threaded Outlet, horizontal installation
2. smooth outlet, horizontal installation

Heating device selecting:

1. without heating device
2. with heating device, 180W heating element is an option, action temperature of the heater is 50-56°C

II. Application:

1. hydromassage bathtub making bubble

III. Instance

1. the nozzle of hydromassage bathtub: APR400、APR800
2. the nozzle of SPA large pool: APR800、APR900

IV. Selection notice:

1. Model, power, voltage (frequency 50/60Hz of air blower's excitation motor is universal, 220-240V, 110-120 V is selectable)
2. Request for outlet fitting size: ϕ 32mm、 ϕ 33.5mm、 ϕ 48.5mm、 ϕ 50mm is available
3. Standard configuration: 1.5m cable, without plug, heater, without air switch (plug, leakage plug, air switch is available)

LX Air blower (APR800V2/APR900V2/APR900-Z):

APR series specification parameter								
Model	Power W	Current(A) 230V/50Hz	Max pressure m	Max air flow m3 / min	Noise dB(A)	Nozzle	Fuse inside motor A	
							230V	110V
APR400V2	400	2.8	1.3	2.2	74	12-24	4.5	7.5
APR800V2	700	3.3	2.1	2.6	78	16-32	7.5	10
APR900V2	900	4.5	2.4	2.7	79	20-40	7.5	10
APR900-Z	700	4.3	2.1	1.4	73	16-32	7.5	10

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: axh@nt-rt.ru || сайт: <https://lx.nt-rt.ru>